An-Najah National University



Networks-Lab
Dr. Muhannad Al-Jabi
Thursday 8:00am – 2:00pm
Summer Semester

Experiment Information	
Experiment Name: DHCP and DNS	Experiment Number: #6
Performed: 7 of July, 2021	Submitted: 24 of July, 2021
Partner Students	
Taher Anaya	Mohammad Badawi

Introduction:

This lab is divided into two sections. The first section discusses DHCP server services and how to configure them. The second one discusses DNS server services and how to configure them. To install and configure services, we use a server with a Windows server.

Objectives:

- ➤ Install the DHCP Server service. And authorize a DHCP server, create a DHCP scope, configure DHCP scope options, and finally configure a DHCP reservation.
- ➤ Install the DNS Server service, then create a forward lookup zone. And finally create reverse lookup zone.

Procedure:

DHCP Server

A DHCP Server assigns IP addresses to client computers for a set length of time via a lease generating process. Because IP address leases are often transitory, DHCP clients must seek to renew their leases with the DHCP server regularly.

DHCP is an Internet Engineering Task Force (IETF) protocol for configuring hosts on a TCP/IP-based network, such as a private intranet, to decrease the administrative cost and complexity. The DHCP Server service automates the process of configuring TCP/IP on DHCP clients.

Configuring Server:


- Turn on the server, then enter username Administrator and password Net123456.
- ➤ Open the network connections control panel. In Network-Connections, open Properties, then double-click on (TCP/IPv4), then choose to use the following IP address, then type 10.0.7.2 and next to Subnet mask type 255.255.255.0. Then type 10.0.7.1 in default-gateway. Finally, close the Network Connections control panel.

Install DHCP Server:

All the steps are written in order and detail inside the manual, so there is no need to re-mention them here.

Creating, Configuring, and Assigning a Scope

- ✓ In the DHCP window, right-click the server on which you want to create the new scope and choose New Scope. The New Scope Wizard appears.
- ✓ Click the Next button on the Welcome page.
- ✓ Enter a name and a description for your new scope and click the Next button.
- ✓ In the IP Address Range page, enter 10.0.7.10 as the start IP address for the scope and 10.0.7.250 as the end IP address. Leave the subnet mask controls alone. Click the Next button.



- ✓ In the Add Exclusions page, click Next without adding any excluded addresses.
- ✓ In the Lease Duration page, set the lease duration to 3 days and click the Next button.
- ✓ In the Configure DHCP Options page, click the Next button to indicate that you want to configure default options for this scope.
- ✓ Enter a router (gateway) IP address (in this case, 10.0.7.1) in the IP Address field and then click the Add button. Once the address is added, click the Next button.

- ✓ In the Domain Name and DNS Servers page, Click the Next button.
- ✓ On the WINS Servers page, click the Next button to leave the WINS options unset and display the Activate Scope page.
- ✓ Select the No; I Will Activate This Scope Later radio button. Click the Next button. When the Wizard Summary page appears, click the Finish button to create the scope.
- ✓ Right-click the server, then select activate command. Use switch 3550 to Connect PC1 and PC2 with DHCP server- Windows Server 2012.
- ✓ In each PC, open a command prompt and type the following commands.
 - o Ipconfig /release Release the IP address for Network Card.
 - Ipconfig /renew Renew the IP address for Network Card.

```
C:\Users\NetworksPC>ipconfig /release
Windows IP Configuration
An error occurred while releasing interface Loopback Pseudo-Interface 1 : The system cannot find the file specified.

Ethernet adapter Local Area Connection:

Connection=specific DMS Suffix .:
Link-local IPv6 Address ... : fe80::bdce:88c1:7969:88a3%11
Default Catevay ... .:
Media State
Connection=specific DMS Suffix .:
C:\Users\NetworksPC>ipconfig /renew
Windows IP Configuration
An error occurred while releasing interface Loopback Pseudo-Interface 1 : The system cannot find the file specified.

Ethernet adapter Local Area Connection:
Connection=specific DMS Suffix .:
1Pv4 Address ... : fe80::bdce:88c1:7869:88a3%11
IPv4 Address ... : 19.8.7.188
Subnet Mack ... : 19.8.7.188
Subnet Mack ... : 19.8.7.189
Default Gatevay ... : 19.8.7.189
Left adapter Local Area Connection:
Connection=specific DMS Suffix .:
19.8.7.188
Subnet Mack ... : 19.8.7.189
Subnet Mack ... : 19.8.7.189
Left adapter isatap.
COGNECTION=Specific DMS Suffix .:
Hedia disconnected
Connection=specific DMS Suffix .:
Hedia State ... : Hedia disconnected
Connection=specific DMS Suffix .:
Connection=specific DMS Suffix .:
Hedia disconnected
Connection=specific DMS Suffix .:
Connection
```

```
C:\Users\NetworksPC\piconfig \renew
Windows IP Configuration
An error occurred while releasing interface Loopback Pseudo-Interface :
stem cannot find the file specified.

Ethernet adapter Local Area Connection:


Connection-specific DNS Suffix :
Link-local IPv6 Address . . . : fe80::dcb8:f84a:cc8b:9f24x11
IPv4 Address . . . : 10.0.7.200
Subnet Mask . . . . . : 255.0.0.0
Default Gateway . . : 10.0.7.1

Tunnel adapter isatap.\C9ACBDCE-69FC-415D-9E85-19B612011D1F\rangle:
Media State . . . . : Media disconnected
Connection-specific DNS Suffix :

Media State . . . : Media disconnected
Connection-specific DNS Suffix : :
```

Creating and Testing a Client Reservation.


✓ In the DHCP window, expand the target server's scope until you see the address leases.



- ✓ Right-click the Address Leases node and click Export List on the pop-up menu.
- ✓ Record the MAC address of PC1 and PC2.
 - At a command prompt, ipconfig /all for each PC.
 - Record the physical address for the Ethernet adapter Intel Gigabit NIC.



- ✓ In DHCP, in the console tree, under the scope that you created in the preceding exercise, click Reservations.
- ✓ Right-click Reservations, and then click New Reservation.
- ✓ In the New Reservation dialog box, in the Reservation name box, type PC1.
- ✓ In the IP address box, type 10.0.7.100.
- ✓ In the MAC address box, type the address of your partner's network adapter for PC1
- ✓ Click Add, and then, Repeat previous two steps for PC2: 10.0.7.200.
- ✓ Click Add, and then click Close.




✓ At a command prompt for each PC, type ipconfig /release. then renew

```
C:\Users\NetworksPC>ipconfig /renew
         \NetworksPC>ipconfig /release
ndows IP Configuration
                                                                                                           Windows IP Configuration
    ror occurred while releasing interface Loopback Pseudo-Interface 1
cannot find the file specified.
                                                                                                           An error occurred while releasing interface Loopback Pseudo-Interface 1 :
stem cannot find the file specified.
       et adapter Local Area Connection:
      nection-specific DNS Suffix .:
k-local lPv6 Address . . .: fe80::bdce:88c1:7060:88a3x11
ault Gateway . . . . . .:
                                                                                                           Ethernet adapter Local Area Connection:
 nnel adapter isatap.{C9ACBDCE-69FC-415D-9E85-19B612011D1F}:
                                                                                                               Connection-specific DNS Suffix :
Link-local IPv6 Address . . : fe80::dcb8:f84a:cc8b:9f24x11
IPv4 Address . . : 19.0.7.200
Subnet Mask . . . : 255.0.0.0
Default Gateway . . . : 10.0.7.1
 Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
\Users\NetworksPC>ipconfig /renew
indows IP Configuration
error occurred while releasing interface Loopback Pseudo-Interfeen cannot find the file specified.
                                                                                                           Tunnel adapter isatap.<C9ACBDCE-69FC-415D-9E85-19B612011D1F>:
    rnet adapter Local Area Connection:
                                                                                                               Media State ...... : Media disconnected Connection-specific DNS Suffix .:
   onnection-specific DNS Suffix :
ink-local IPv6 Address : fe80::bdce:88c1:7060:88a3x11
Pv4 Address : 10.0.7.100
ubnet Mask : 255.0.0
fault Gateway : 10.0.7.1
                                                                                                            Tunnel adapter 6T04 Adapter:
nnel adapter isatap.{C9ACBDCE-69FC-415D-9E85-19B612011D1F}:
                                                                                                               Media State . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
 Media State . . . . . . . . . : Media disconnected Connection-specific DNS Suffix . :
```

> Removing DHCP.

- ✓ Open Server Manager. Then on a local server, select DHCP. Select tools, then remove the rule.
- ✓ In the Windows Components wizard, on the Windows Components page, click Networking Services, and then click Details.
- ✓ In the Networking Services dialog box, clear the Dynamic Host Configuration Protocol (DHCP) check box, and then click OK.
- ✓ On the Windows Components page, click Next.
- ✓ When the configuration process is complete, click Finish.




DNS Server

In Internet Protocol (IP) networks, the Domain Name System (DNS) is an essential component of client/server communication. DNS is a distributed database used in IP networks to translate computer names into IP addresses or resolve them.

Installing the DNS Server Service.

All the steps are written in order and detail inside the manual, so there is no need to re-mention them here. But there are some screenshots we should include here.

Forward and Reverse Lookup Zone:



Ping PC1 and PC2 and Server:

```
C:\Users\NetworksPC\ping PC1.lab.com

Pinging PC1.lab.com [10.0.7.3] with 32 bytes of data:
Reply from 10.0.7.3: bytes=32 time/ims IIL=128
Reply from 10.0.7.4: bytes=32 time/ims IIL=128
Reply from 10.0.7.2: bytes=
```

To know the name:

```
C:\Users\NetworksPC>nslookup 10.0.7.2

Server: server
Address: 10.0.7.2

Name: server
Address: 10.0.7.2

C:\Users\NetworksPC>nslookup 10.0.7.3

Server: server
Address: 10.0.7.2

Name: pc1
Address: 10.0.7.3

C:\Users\NetworksPC>nslookup 10.0.7.4

Server: server
Address: 10.0.7.2

Name: pc1
Address: 10.0.7.3
```

> Conclusion.

In this experiment, we learned how to set up a DHCP server and receive a dynamic IP address from it. Authorize a DHCP server, construct a DHCP scope, configure DHCP scope options, and configure a DHCP reservation is also covered.

And, we learned how to set up a DNS server and configure it to convert IP addresses to domain names and vice versa automatically. We also learn how to construct a DNS forward and reverse lookup zoon and authorize a DNS server.